

### List of Model Examiner Model checks covering MAAB 2.0 Guidelines

No.	ID	Title	Repair option available	Parameterizable
1	jc_0201	Usable characters for Subsystem names	yes	
2	jc_0211	Usable characters for Inport block and Outport block	yes	
3	jc_0221	Usable characters for signal line name	yes	
4	jc_0231	Usable characters for block names	yes	
5	jc_0011	Optimization parameters for Boolean data types	yes	
6	jc_0021	Model diagnostic settings		yes
7	na_0004	Simulink model appearance	yes	yes
8	db_0043	Simulink font and font size		
9	db_0042	Port block in Simulink models	yes	
10	jc_0081	Icon display for Port block	yes	
11	db_0142	Position of block names		
12	jc_0061	Display of block names	yes	yes
13	jm_0013	Annotations	yes	
14	db_0032	Simulink signal appearance		
15	jc_0281	Naming of Trigger Port block and Enable Port block	yes	
16	jm_0010	Port block names in Simulink models	partial	
17	na_0008	Display of labels on signals	yes	yes
18	db_0081	Unconnected Ports and Signals		
19	jm_0001	Prohibited Simulink standard blocks inside controllers		yes
20	hd_0001	Prohibited Simulink sinks		yes
21	na_0011	Scope of Goto and From blocks	yes	
22	jc_0141	Use of the switch block		yes
23	jc_0121	Use of the Sum Block	yes	
24	jc_0131	Use of Relational Operator block		
25	jc_0111	Direction of Subsystem	yes	
26	db_0123	The name of a Stateflow input/output is the same as the corresponding signal		
27	db_0129	Stateflow transition appearance		
28	db_0122	Stateflow/Simulink interface signals and parameters	yes	